




FRONT SUSPENSION

	<p>"3879" - Sway Bar End Link Bushing Kit - \$32 per Kit Sway bar end link bushing kit is comprised of (8) correct durometer black bushings, (8) black zinc plated conical washers, and (4) phosphated 5/16-18 nuts. Designed to be used with original end links or original bolts & spacers. One kit required per sway bar.</p>
	<p>"5188" - Sway Bar End Link Kit- \$55 per Kit Sway bar end links used on late 1966-69 A & B-Body front and T/A and 1971 and later E-Body rear sway bars. Correct black phosphated end links, 8 correct durometer urethane end link bushings, 8 correct conical washers finished in black zinc, and 4 phosphated 5/16-18 nuts. One kit required per car.</p>
	<p>"5992" - Sway Bar End Link Kit- \$50 per Kit Sway bar end links used on E-Body and 1970-72 B-Body front sway bars. Correct "L5" headed black phosphate end link bolts, two phosphated rolled spacers, 8 correct durometer urethane end link bushings, 8 correct conical washers finished in black zinc, and 2 phosphated 5/16-18 nuts. One kit required per car.</p>